


Additional instruments



- E 1 - Lighting switch
- E 20 - Switches and instruments - lighting control
- F 22 - Oil pressure switch (0.3)
- G 8 - Oil temperature sender
- G 9 - Oil temperature gauge
- G 10 - Oil pressure sender
- G 11 - Oil pressure gauge
- G 14 - Voltmeter
- J 166 - Instrument lighting amplifier
- L 15 - Ashtray light bulb
- L 28 - Cigarette lighter light bulb
- T 2 s - Connector, 2-pin, brown, behind console
- T 6 w - Connector, 6-pin, white, behind console
- T 8 e - Connector, 8-pin, in engine compartment, right
- T 26 - Connector, 26-pin, yellow, on dash panel insert
- U 1 - Cigarette lighter

- (199) - Earth connection -3-, in dash panel wiring loom
- (A19) - Connection (58d), in dash panel wiring loom
- (A23) - Connection (30a1), in dash panel wiring loom