


Dash panel insert, speedometer, coolant monitor, voltage stabiliser



Wiring colours:

- bl = blue
- br = brown
- ge = yellow
- gn = green
- gr = grey
- li = purple
- ro = red
- sw = black
- ws = white

- G – Fuel gauge
- G 3 – Coolant temperature gauge
- G 21 – Speedometer
- G 22 – Speedometer sender
- J 6 – Voltage stabilizer
- K 1 – Main beam warning lamp
- L 10 – Dash panel insert light bulb
- T 3r – Connector 3 pin, white, in luggage boot, left
- T 10 – Connector 10 pin, black, connector point in aux. relay carrier
- T 26 – Connector 26 pin, yellow, on dash panel insert
- T 26a – Connector 26 pin, blue, on dash panel insert
- 81 – Earth connection – 1 –, in dash panel wiring loom
- 83 – Earth connection – 1 –, in front right wiring loom
- 86 – Earth connection – 1 –, in rear wiring loom
- 98 – Earth connection, in tailgate wiring loom
- A42 – Connection (fuel gauge), in dash panel wiring loom