


Audi Coupé (2.3 litre fuel injection engine, 98 kW, KE-III Jetronic, 5-cylinder) Engine code letters NG


from July 1992

Position of relays,
also see "Fitting Locations"

Relay plate with fuse holder:



Auxiliary relay carrier,
front (under left dash panel)



Position of relays:


- 1** – Relay for fog lights
– Bridge connection with rear fog lights
- 2** – Radiator fan relay, 2nd stage
- 3** – Control unit for radiator fan run-on
- 4** – Relay for headlight washer system
- 5** – Relief relay for X-contact
- 7** – Relay for horn
- 8** – Bridge connection with manual gearbox
– Relay with anti-theft alarm (starter inhibitor)
- 9** – Relay for intermittent windscreen wash/wipe system
- 10** – Fuel pump relay
- 11** – Radiator fan relay, 1st stage

Fuse colours

- 30 A – green
- 25 A – white
- 20 A – yellow
- 15 A – blue
- 10 A – red
- 5 A – beige

Position of relays:

Auxiliary relay carrier, rear
(under left seat bench)



Position of relays: