



Earth connections



- bl = blue
- br = brown
- ge = yellow
- gn = green
- gr = grey
- li = lilac
- ro = red
- sw = black
- ws = white



97-16612

- (11) - Earth point, in battery box
- (14) - Earth point, on gearbox
- (17) - Earth point, on intake manifold
- (32) - Earth point, behind dash panel, left
- (81) - Earth connection -1-, in dash panel wiring loom
- (83) - Earth connection -1-, in front right wiring loom
- (84) - Earth connection, engine block, in front right wiring loom
- (86) - Earth connection -1-, in rear wiring loom
- (119) - Earth connection -1-, in headlight wiring loom
- (199) - Earth connection -3-, in dash panel wiring loom