


Headlights, side lights, headlight range control



- E 102 - Headlight range control adjuster
- L 1 - Twin filament bulb for headlight, left
- L 2 - Twin filament bulb for headlight, right
- M 1 - Side light bulb, left
- M 3 - Side light bulb, right
- T 4 - Connector, 4-pin, near headlight, left
- T 4 a - Connector, 4-pin, near headlight, right
- T 10 a - Connector, 10-pin, yellow, on connector point, aux. relay carrier
- V 48 - Left motor for beam adjustment
- V 49 - Right motor for beam adjustment

- (119) - Earth connection -1-, in headlight wiring loom
- (199) - Earth connection -3-, in dash panel wiring loom