
## Electric sliding roof with preselector, Audi Coupé


From July 1991

Position of relays – also see "Fitting Locations"

Relay plate with fuse holder:

Auxiliary relay carrier, front (under dash panel, left)






Position of relays:

Position of relays:

Auxiliary relay carrier, rear (under rear seat bench, left)



Position of relays:

## **Fuse colours**

30 A - green

25 A – white


20 A - yellow

15 A - blue

10 A - red

5 A - beige

## Electric sliding roof with preselector



ge = yellow gn = green

Wiring colours: ro = red sw = black br = brown

bl = blue

gr = grey

ws = white

li = purple

E 139 - Regulator for sliding roof adjustment

G 21 - Speedometer

J 245 - Control unit for sliding roof adjustment

S 83 - Thermo fuse for sliding roof

T 2ao - Connector 2 pin, green, behind dash panel, left

T 4m — Connector 4 pin, near potentiometer

T 26a - Connector 26 pin, blue, on dash panel insert

V 1 - Sliding roof motor

32 – Earth point, behind dash panel, left

Connection (15a), in dash panel wiring loom

Connection (speed signal), in dash panel wiring loom

can be used on any free relay position

97-7613